

INSTALLATION INSTRUCTIONS FOR LED REMOTE HEAD

IMPORTANT SAFEGUARDS

READ AND FOLLOW ALL SAFETY INSTRUCTIONS

When using electrical, basic safety precautions should always be followed including the following.


1. Disconnect power at fuse or circuit breaker before installing or servicing.
2. Do not use outdoors.
3. Do not mount in hazardous locations, or near gas or electric heaters.
4. Do not let power cords touch hot surface.
5. Equipment should be mounted in locations and at heights where it will not be subjected to tampering by unauthorized personnel.
6. The use of accessory equipment not recommend by the manufacturer may cause an unsafe condition.
7. Do not use this equipment for other than intended use.
8. All servicing should be performed by a qualified personnel only.

SAVE THESE INSTRUCTIONS

Instruction

1. Connect wires to DC 3.6V supply in accordance with local and national code.
2. Secure fixture to junction box with hardware provided.

Wiring Diagram



Singel head Max. mounting height 14ft

Dual heads Max. mounting height 20ft